




COOKTOP PARTS

FOR MODELS: RF303PXXQ2, RF303PXXW2, RF303PXXT2

(Designer White) (White) (Biscuit)

30" ELECTRIC FREESTANDING
STANDARD CLEAN RANGE



Illus. No.	Part No.	DESCRIPTION
1	9759923	Literature Parts
	9757142	Instructions, Installation
	9757143	Template, Anti-Tip
	8522768	English/Spanish
	4454084	English/French
	3191638	Guide, Use & Care
		Sheet, Tech
		Safer Cooking Tips

Illus. No.	Part No.	DESCRIPTION
2	3195208	Bowl, Drip
	3195209	6" Chrome (3)
		8" Chrome (1)
3	3186235	Cooktop
	8273508	White
		Biscuit
4	3195060	Hinge, Cooktop (2)
5	3196178	Screw


Illus. No.	Part No.	DESCRIPTION
6	308605	Strain Relief
7	3195812	Rod, Support (2)
8	3195917	Clip, Spring
9	814399	Receptacle, Elmnt
10	3196154	Screw
11		Element, Surface
		(Includes #8)
	8053265	6" (3)
	8053267	8" (1)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

FOR MODELS: RF303PXXKQ2, RF303PXXKW2, RF303PXXKT2

(Designer White) (White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	3186190	Endcap
	3186188	Left Hand-White
	8272507	Left Hand-Black
	3186191	Left Hand-Biscuit
	3186189	Right Hand-White
	8272508	Right Hand-Black
2	8272508	Right Hand-Biscuit
	8523408	Support, Endcap
	8523409	Left Hand
3	3186163	Right Hand
	9759807	Panel, Backguard
	9759807	White
	9759807	Black
	9759806	Biscuit


Illus. No.	Part No.	DESCRIPTION
4	3148953	Switch, Infinite
	3148951	Use W/ 8" Element
	3148951	Use W/ 6" Element
5	8273303	Indicator, Surface
6	3188987	Switch, Selector
7	8524329	Thermostat
8	314031	Indicator, Oven
9	8273564	Clip
10	3196200	Clip, Spring (2)
11	8522565	Knob, Infinite (5)
	8522565	White
	8522566	Black
	8522567	Biscuit

Illus. No.	Part No.	DESCRIPTION
12	3149360	Switch, Rocker
13	3196068	Lens, Ind. (2)
14	8522619	Knob, Thermostat
	8522620	White
	8522621	Black
15	8053912	Biscuit
16	4449746	Shield, Heat
17	8272473	Screw
18	9758283	Cover, Upper Rear
19	3196178	Box, Cover
20	3196170	Screw
21	3400882	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

FOR MODELS: RF303PXXKQ2, RF303PXXKW2, RF303PXXKT2
(Designer White) (White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

FOR MODELS: RF303PXKQ2, RF303PXKW2, RF303PXKT2

(Designer White) (White) (Biscuit)


Illus. No.	Part No.	DESCRIPTION
1	3169143	Vent Tube
2	3186144	Box, Burner
3		Panel, Side (2)
	8053830	White-Textured
	8272519	Biscuit-Textured
4	313382	Clip, Thermobulb
5	3186152	Seal, Oven Door
6	9757340	Element, Broil
7	9758541	Element, Bake
10	3195546	Glide, Drawer Frnt
11	3196037	Foot, Front (2)
12	9758224	Frame, Front
13	8054068	Tray, Insulation
14	3196576	Clip, Panel (6)
15	9760314	Rail, Base (2)
16	312701	Foot, Rear (2)
18	3195809	Bumper, Side (2)
19	3186116	Support, Oven (2)
20	3186034	Bracket, Service
21	9757136	Block, Terminal
	112432	Nut (3)
22	8274034	Back, Main
23	3196169	Screw
25	3196567	Screw
26	3196168	Screw
27	3196174	Screw
28	3196165	Screw
29	3196179	Screw
30	3196178	Screw
31	3400016	Screw
34	3196177	Screw
35	3196701	Light Socket Assy
36	311255	Bulb, Oven Light

INSULATION

8273263 Insulation, Wrap
8272611 Insulation, Back

DRAWER & BROILER PARTS

FOR MODELS: RF303PXXQ2, RF303PXXW2, RF303PXXT2
(Designer White) (White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (2)
4	8272605	Drawer, Storage
5	9758200	Bracket, Drawer(2)
6		Rivet, Push (2)
	3196814	White
	3196815	Biscuit
7		Panel, Drawer Frnt
	8053339	White
	8272501	Biscuit
9	8053334	Glide, Drawer (2)
10	3196168	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

FOR MODELS: RF303PXKQ2, RF303PXKW2, RF303PXKT2

(Designer White) (White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	8522433	Trim, Top
	3196819	White
	8522434	Black
	8522434	Biscuit
2	3196164	Screw
3	8522444	Handle, Door
	3195922	White
	8522445	Black
	8522445	Biscuit
4	3186296	Liner, Door
6	8053808	Hinge, Door (2)

Illus. No.	Part No.	DESCRIPTION
7	8523172	Trim, Door (2)
	8523172	Left Hand-White
	8523171	Left Hand-Black
	8523173	Left Hand-Biscuit
	8523166	Right Hand-White
	8523165	Right Hand-Black
	8523167	Right Hand-Biscuit
8	8053481	Glass, Door
	8053479	White
	8053479	Black
	8273525	Biscuit

Illus. No.	Part No.	DESCRIPTION
9	3196160	Screw
10	8523175	Trim, Lower
11	3196025	Clip, Glass (4)
12	9758163	Window, Inner
13	3186303	Retainer, Insul.
15	3195809	Bumper, Door (2)
16	3196925	Clip, Door Stop
17	3196161	Screw
18	3196165	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

FOR MODELS: RF303PXXKQ2, RF303PXXKW2, RF303PXXKT2

(Designer White) (White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

SPLICING WIRES--25FT.

LENGTH

242828	Wire, Black	12 Ga. 150° c
242821	Wire, Blue	14 Ga. 150°c
242822	Wire, Brown	14 Ga. 150°c
242830	Wire, Brown	14 Ga. 200°c
242823	Wire, Green	14 Ga. 150°c
242824	Wire, Orange	14 Ga. 150°c
242825	Wire, Red	14 Ga. 150°c
242831	Wire, Red	14 Ga. 200°c
242827	Wire, Yellow	14 Ga. 150°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean(1/2 Pt)
261582	Grease

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

INSULATION

261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
240132	Insulation, Fiberglass (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond
4392899	Biscuit
511873	White Porcelain (2 Oz.)

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350956	Almond
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)
4392900	Biscuit (Uncut)

ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')
3184478	Cleaner, Glass
4396923	Broiler Pan Assy

ANTI-TIP KIT

9757976	Anti-Tip Kit
---------	--------------

WIRING HARNESS PARTS

3196155	Harness, Cooktop
3196520	Clip, Wire
313660	Clip, Ground Wire
3196173	Screw
311227	Wire, Ground
3196154	Screw, Grnd-Cktop
3196174	Screw, Grnd-Back

Miscellaneous

3196897	Pin Kit-Dr Removal
---------	--------------------

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST